



## Attaching a water bladder to Road Sack



The following are instructions to mount a water bladder into Road Sack.

The benefits of this is that you do not have to carry a bulky water bottle and you will have instant & constant access to fluids which is important on those long rides in the summer.

The bladder will occupy and be protected by the padded laptop compartment.

### WARNING&DISCLAIMER:

Take care when performing the mod as to not damage the fabric weave and plastic buckles. We are not liable for any damage resulting from following/not following these instructions .

### What you will need...

- Your Road Sack.
- A replacement water bladder. Typically 1 or 1.5 Litres.
  - Have your local sports or luggage shop order one of any brand in for you. Make sure it comes with the flexible pipe and mouth piece.
- A Philips (+)screw driver, any size.

**Instructions:**

1. Empty out your Road Sack and insert the bladder bag into the laptop compartment.
2. Decide if you want the water tube on the left or the right hand side. Take a Philips screwdriver and drive it from the inside, top (left or right) corner, aim the opening so it's located 2 inches from the corner and edge of backpack so the tube can exit from the adjustable shoulder strap slot.
3. Use a twisting action to push the head through the fabric mesh. Try to push aside the fabric weave and not to abrade the fabric.
4. Once the opening exists, enlarge it by circling the screwdriver tubing. When barely large enough, push the mouthpiece through the hole you've made. Aim for a tight fit.
5. Pull out the rest of the tubing from the outside and loop it as you see fit through the available clips and hoops along the shoulder strap.
6. Fill it up and give it a go !

